

TROUBLESHOOTING VARIPUMP CONTROLLER FAULT CODES

In the unlikely event of an issue developing with the pump, a 3 digit fault code may display on the controller screen. Use the chart below to understand what these codes mean.



If the controller displays digits but the pump is not working - pull out the power cord and re-start.

FAULT CODE	FAULT	RESOLUTION
E01	Pump is out of water	The pump is working without water.
E02	Over current	Abnormal load over current protection. Please pull out the power plug and re-plug again.
E03	Default phase	Bad contact or disconnect in the motor connection.
E05	Locked rotor	Rotation clogging protection, if the pump still not working after restart for three times, please re-plug the power.
E06	Over voltage	Over voltage protection when the working voltage is higher than the rated voltage.
E07	Under voltage	Low voltage protection when the working voltage is lower than the rated voltage.